STICK IT TO TRICKY LINERS

TransferRite AirMask® is our answer to one of the industry's biggest problems. Air egress vinyls have channels that greatly reduce air entrapment to avoid bubbles, but most premasks don't stick to their textured liners. AirMask's *VLTRA®* adhesive is specifically engineered to adhere to areas of exposed air egress liners.



AirMask® From the makers of TransferRite®

AirMask 510U medium tack | transparent film Excellent for partial wraps Designed for use with exposed air release vinyls

ULTRA® adhesive provides superior adhesion to liner Tear resistant



TransferRite's AirMask makes installing partial vehicle wraps a breeze. Once you've positioned your graphic and peeled off the liner, squeegee the decal down firmly, working from the center to the outside.

Photos courtesy of Underground Graphics www.undergroundgraphics.com



Once the decal has been fully squeegeed, gently pull the AirMask back over itself and it will release smoothly, leaving no residue behind.



When the AirMask is removed, you'll reveal a clean and pristine partial vehicle wrap that your customers will love.

We also offer a paper version that features the same revolutionary adhesive properties.

992U high tack | premium, heavyweight paper



GET IN TOUCH TODAY

856-778-0708 • info@abitape.com W W W . A B I T A P E . C O M

